



## **Assembly Instructions For Accuform Ace Bunker Rakes**

1. Insert handle into hole on the rake head – making sure the Accuform logo on the rake head is facing the handle.
2. Apply pressure until the tip of the handle is flush with the rake head.
3. Place the self-tapping screw in the pre-drilled screw hole in the rake head and tighten by applying downward pressure.

**Note: Do not over tighten the self-tapping screw or it may result in stripping out the fiberglass handle.**

Par Aide Products Co.

6800 Otter Lake Road • Lino Lakes, MN 55038-4427 • PHONE: (651) 429-4513 • FAX: (651) 429-4519



## **Assembly Instructions For Accuform Ace Bunker Rakes**

4. Insert handle into hole on the rake head – making sure the Accuform logo on the rake head is facing the handle.
5. Apply pressure until the tip of the handle is flush with the rake head.
6. Place the self-tapping screw in the pre-drilled screw hole in the rake head and tighten by applying downward pressure.

**Note: Do not over tighten the self-tapping screw or it may result in stripping out the fiberglass handle.**

Par Aide Products Co.

6800 Otter Lake Road • Lino Lakes, MN 55038-4427 • PHONE: (651) 429-4513 • FAX: (651) 429-4519