



1) Installing Posts & Attaching Ball Washer

- The 40" Tee Pro post is designed to be permanently cemented into the ground. To properly install, the post should be buried and cemented 14" into the ground, leaving 26" of the post above ground.
- For Single Post Design – after post is installed, attach the ball washer bracket (which is already fixed to the bottom of the ball washer) onto the post –using the four enclosed screws.

1) Installing Posts & Attaching Ball Washer

- The 40" Tee Pro post is designed to be permanently cemented into the ground. To properly install, the post should be buried and cemented 14" into the ground, leaving 26" of the post above ground.
- For Single Post Design – after post is installed, attach the ball washer bracket (which is already fixed to the bottom of the ball washer) onto the post –using the four enclosed screws

1) Installing Posts & Attaching Ball Washer

- The 40" Tee Pro post is designed to be permanently cemented into the ground. To properly install, the post should be buried and cemented 14" into the ground, leaving 26" of the post above ground.
- For Single Post Design – after post is installed, attach the ball washer bracket (which is already fixed to the bottom of the ball washer) onto the post –using the four enclosed screws.

1) Installing Posts & Attaching Ball Washer

- The 40" Tee Pro post is designed to be permanently cemented into the ground. To properly install, the post should be buried and cemented 14" into the ground, leaving 26" of the post above ground.
- For Single Post Design – after post is installed, attach the ball washer bracket (which is already fixed to the bottom of the ball washer) onto the post –using the four enclosed screws.