



Parts List

- 1 – Black 34” Pipe
- 1 – Master Par Aide Ballwasher
- 1 – Portable Ballwasher base
- 2 – Towel clips
- 1 – Allen wrench
- 1 – Gasket (additional)
- 1 – Allen screw
- 1 – Ballwasher drain plug wrench
- 1 – Clamp
- 2 – Bolts
- 2 – Nuts
- 3 – Base spikes

Instructions

Step 1

Take 34” pipe and insert end with screw end up.

Step 2

Take clamp, 2 bolts and 2 nuts and tighten clamp around pipe (on the underside of base), so pipe is snug.

Step 3

Slide Master ballwasher into pipe and take allen screw and insert in opening and tighten so that ballwasher cannot be pulled out of pipe.

Additional Steps

To fill with water, take off top of ballwasher, by loosening allen screws with allen wrench on each side of ballwasher and fill with water. To drain water pull ballwasher out of pipe and use drain plug wrench to loosen drain plug and water will drain out.

Place towel clips in each hole at the bottom of ball washer, towels can then be hung from clips.

If putting ballwasher outside screw 3 base spikes into base and ballwasher can be stabilized into ground.